

Insert Driver

The Model TA Automatic Self-Tapping Insert Driver combines automatic parts feeding and installation of self-tapping, threaded inserts into one compact, efficient system. The inserts are fed into an insertion unit where they await a signal that is initiated by the operator or system controller. The unit then advances and rotates simultaneously, screwing the insert in to a preset depth. A switch then reverses the rotation of the unit, thereby unscrewing it from the insert.

Source URL (retrieved on 01/26/2015 - 2:45am):

http://www.mdtmag.com/product-releases/2003/07/insert-driver?qt-recent_content=0&qt-video_of_the_day=0